

XK8 URETHANE SHOCK MOUNT KIT INSTALLATION INSTRUCTIONS

- 1) Remove old shock mount assembly from your XK8**
- 2) Using a 3/16" drill bit, drill out the rivets of the shock plate, and remove the old rubber bushings**
- 3) Prepare shock plates by removing any old material stuck to them, and clean the surface**
- 4) Lubricate shock plates with a silicone based lubricant (important that it is not petroleum based)**
- 5) Place both small urethane bushings in the center of mount**
- 6) Place shock plate on top of bushings**
- 7) Install new washers and bolts, making sure to tighten evenly until bushings are compressed**
- 8) When compressed, install new rivets**
- 9) Remove nuts and washers**
- 10) Install large urethane bushing and shock mount top cover**
- 11) Re-install shock mount on vehicle**