

XJS LEAPER INSTRUCTIONS

Step 1) Remove front grille

Step 2) Open the bonnet and remove bonnet struts from the hood. Prop the bonnet open with a prop rod, broom handle or a friend.

Step 3) Remove the bonnet badge

Step 4) Once inside the bonnet where the original badge was mounted, drill a 1.5" hole on the bottom of the bonnet to remove the inner structure only. This is necessary to make room for the new large nylon nut that will keep the new leaper in place.

Step 5) Drill a 11/16" hole through the top of the bonnet to make room for the break away spring on the spring loaded leaper. The nylon nut will attach to this spring.

Step 6) If necessary, buff out the area where the bonnet badge was.

Step 7) Mount XJS Leaper. Be sure not to over tighten nylon nut.

Step 8) Reinstall bonnet struts

Step 9) Reinstall grille

Step 10) Admire new leaper

