

S-TYPE LOWER MESH GRILLE

INSTALLATION INSTRUCTIONS



BEGIN BY REMOVING THE HORIZONTAL VANE IN LOWER BUMPER/GRILLE OPENING. IT IS HELD BY THREE QUARTER TURN TURNBUCKLE FASTENERS; ONE IN THE CENTER AND TWO TOWARDS EACH END.

ONCE REMOVED, BEGIN INSTALLATION BY INSERTING THE THREE PLASTIC PLUGS INTO THE TURNBUCKLE RECEPTACLES AT POINTS WHERE VANE WAS REMOVED.

NEXT, POSITION THE NEW MESH INSERT INTO THE LOWER OPENING HOLDING WITH LIGHT PRESSURE. FASTEN IN PLACE BY INSERTING THE THREE PHILLIPS HEAD SCREWS INTO THE PLASTIC PLUGS THROUGH THE CORRESPONDING HOLES IN THE GRILLE MESH.

WELSH ENTERPRISES INC.

WWW.WELSHENT.COM - 800-875-5247 - INFO@WELSHENT.COM