

# **JAGUAR XJ6 (95-97) MESH INSERTS**

## **INSTALLATION INSTRUCTIONS**



- 1 - REMOVE THE "2" PHILLIPS HEAD SCREWS AT THE TOP OF EACH GRILLE VANE INSERT.**
- 2 - PULL VANE ASSEMBLY FORWARD AND UPWARDS TO REMOVE.**
- 3 - REMOVE CLIPS AT UPPER OPENINGS OF GRILLE SURROUND AT POINTS WHERE PHILLIPS SCREWS WERE REMOVED.**
- 4 - INSTALL CLIPS SUPPLIED WITH GRILLE MESH WITH "FLAT SIDE" FACING FORWARD AT THESE POINTS.**
- 5 - INSTALL MESH INSERTS BY INSERTING LOWER ALIGNMENT TABS INTO CORRESPONDING SLOTS IN LOWER PORTION OF GRILLE SURROUND OPENINGS.**
- 6 - SECURE TOP OF GRILLE MESH INSERTS BY INSERTING THE PHILLIPS SCREWS INCLUDED WITH NEW CLIPS THROUGH THE TOP SCREW HOLES ON FACE OF MESH AND INTO THE CLIPS INSTALLED ON STOP 4.**

**WELSH ENTERPRISES INC.**

**WWW.WELSHENT.COM - 800-875-5247 - INFO@WELSHENT.COM**