

JAGUAR XJ40 MESH GRILLE INSERTS

INSTALLATION INSTRUCTIONS



1 - UNSCREW AND REMOVE VANE INSERTS.

2 - REMOVE PLUGS THAT HELD OLD SCREWS BY SQUEEZING WITH PLIERS TO BREAK AWAY LIP. PUSH REMAINING PIECE THROUGH WITH FLAT-HEAD SCREW DRIVER.

3 - PUT 2 OF BRACKETS SUPPLIED IN THE TOP HOLES OF ONE SIDE WITH SCREW HOLES FACING YOU.

4 - PLACE MESH INSERTS INTO BOTTOM HOLES. REACH BEHIND AND WHILE HOLDING BRACKETS; SCREW IN THE TOP 2 SCREWS.

5 - PUT 2 BRACKETS IN THE TOP HOLES OF SECOND SIDE. PLACE MESH INSERT INTO BOTTOM HOLES. BE CAREFUL NOT TO LET BRACKETS IN TOP HOLES DROP. SINCE YOU CAN NO LONGER REACH BEHIND, USE THE SHORT END OF SMALL ALLEN WRENCH TO HOLD BRACKET WHILE SCREWING IN THE LAST 2 SCREWS.

WELSH ENTERPRISES INC.

WWW.WELSHENT.COM - 800-875-5247 - INFO@WELSHENT.COM