

JAGUAR XJ8 (98-03) MESH INSERTS

INSTALLATION INSTRUCTIONS



1 - UNCLIP THE VANE ASSEMBLIES, PRYING IN A DOWNWARD MOTION WITH A FLAT BLADED SCREWDRIVER BETWEEN THE TOP OF VANE AND THE GRILLE SURROUND OPENINGS.
(PUSHING WITH DOWNWARD FORCE ON SCREWDRIVER HANDLE AS NOT TO MAR GRILLE SURROUND FACE)

2 - PULL VANE ASSEMBLY FORWARD AND UPWARDS TO REMOVE.

3 - INSTALL MESH INSERTS BY INSERTING LOWER ALIGNMENT TABS INTO CORRESPONDING SLOTS IN LOWER PORTION OF GRILLE SURROUND OPENINGS.

4 - SECURE TOP OF GRILLE MESH INSERTS BY INSERTING THE PHILLIPS SCREWS THROUGH THE TOP SCREW HOLES ON FACE OF MESH AND INTO HOLES OF CORRESPONDING TABS OF GRILLE SURROUND.

WELSH ENTERPRISES INC.

WWW.WELSHENT.COM - 800-875-5247 - INFO@WELSHENT.COM