

JAGUAR XK8 MESH GRILLE INSERT

INSTALLATION INSTRUCTIONS



- 1 - REMOVE PLASTIC PUSH PINS LOCATED AT THE TOP OF THE OVERRIDERS. THERE WILL BE TWO ON EACH.
- 2 - GENTLY SQUEEZE THE BOTTOM BUMPER COVER TO REMOVE OVERRIDERS.
- 3 - REMOVE GRILLE BOLTS. THERE IS ONE ON EACH END OF THE GRILLE.
- 4 - PLACE MESH GRILLE UP TO THE CAR TO DETERMINE METAL SCREW PLACEMENT ONTO THE OVERRIDER BRACKETS. DRILL HOLES IN OVERRIDER BRACKETS AND SCREW THE GRILLE ONTO BRACKETS WITH SCREWS.

(FOR 2004 AND UP MODELS - USE THE PRE MADE SCREW PLACEMENT SPOTS ALREADY INSTALLED IN MESH TO MOUNT ONTO YOUR CAR)

WELSH ENTERPRISES INC.

WWW.WELSHENT.COM - 800-875-5247 - INFO@WELSHENT.COM